

- ① SINGULAIR® AERATOR, AS TESTED AND
- ② FALL THROUGH SINGULAIR® PLANT FROM INLET INVERT TO OUTLET INVERT IS FOUR INCHES. INLET INVERT IS 16 INCHES BELOW THE RISER MOUNTING
- ③ ON DEEPER INSTALLATIONS, RISERS MUST BE USED TO EXTEND AERATOR MOUNTING RISER AND BIO-KINETIC® SYSTEM MOUNTING RISER TO GRADE. INSPECTION COVER ON PRETREATMENT CHAMBER MUST BE DEVELOPED TO WITHIN TWELVE INCHES OF GRADE.
- (4) REMOVABLE COVERS ON RISERS ARE EACH SECURED TO PREVENT UNAUTHORIZED ACCESS.
- (5) THE NUMBER OF SPRAY UNITS WILL VARY DEPENDING ON SPECIFIC SITE

•	SINGULAIR® DISTRIBUTOR FOR ELECTRICAL REQUIREMENTS.			
	PROJECT ENGINEER'S APPROVAL: I (WE) HEREBY CERTIFY THAT THIS DRAWING HAS BEEN CHECKED AND IS APPROVED FOR USE IN CONFORMITY WITH THE CONTRACT DOCUMENTS.			
	DATE:			
	NAME:			
	CONTRACTOR'S CERTIFICATION: I (WE) HEREBY CERTIFY THAT THIS DRAWING HAS BEEN CHECKED AND IS APPROVED FOR USE IN CONFORMITY WITH THE CONTRACT DOCUMENTS.			
	DATE:			
	CRITICAL DIMENSIONS			
	Α	1'- 5 1/2"	N	0'- 0 3/8"
	В	3'- 3"	O	0'- 6"
	С	3'- 5 1/4"	P	0'- 0 3/8"
	D	4'- 2 1/4"	Q	1'- 8"
	Е	2'- 8 3/4"	R	4'- 3 1/2"
	F	10'- 6 1/2"	S	
	G	1'- 4"	T	
	Н	4'- 7 1/2"	U	
	ı	0'- 3"	V	
	J	0'- 1 1/2"	W	
	K	1'- 0"	X	
	L	0'- 0 3/4"	Y	
	II BA	41 411		I

NPD

JMM

12-10-2020

PC-5-7199